

Useful CLI commands F5OS

CLI commands

[ConfD](#) on F5 is the CLI tool to get and set all config of the F5. You can get the same configuration options like in the F5OS UI.

Use "su admin" to start an interactive shell when you are logged in as root via ssh.

Useful CLI command line troubleshooting tools

Command	Description
show system licensing	The output displays licensing information for the F5OS system, including a list of active modules.
show system state	The output displays the state about the F5OS system, like hostname, date/time, mac address...

show system image

Shows System Image information.
Example:

```
appliance-1# show system image

IN
VERSION OS      STATUS  DATE          SIZE
USE      TYPE
-----
1.5.1-12283  ready   2023-08-14  926.15MB
true

VERSION                                IN
SERVICE          STATUS  DATE          SIZE
USE      TYPE
-----
1.5.1-12283  ready   2023-08-14  4.55GB
true
1.5.0-5781   ready   2023-08-14  4.55GB
false

VERSION ISO  STATUS  DATE          SIZE
USE      TYPE
-----
1.5.1-12283  ready   2023-08-14  6.05GB
false
```

show components component platform state	<p>Displays hardware info, serial-no, part-no, memory, temperature and more of the platform. Example:</p> <pre>appliance-1# show components component platform state state description r5600 state serial-no f5-wdbb-iodf state part-no "203-0411-05 REV B" state empty false state tpm-integrity-status Valid state memory available 9573109760 state memory free 4797321216 state memory used-percent 93 state memory platform-total 16107667456 state memory platform-used 5998272512 state temperature current 21.4 state temperature average 22.2 state temperature minimum 21.2 state temperature maximum 23.5</pre>
show port-mappings	<p>The output displays information about port mappings and pipelines. For more infos check the documentation: F5OS-A for rSeries Architecture F5OS-C for VELOS Architecture</p>

show portgroups

shows the installed optics in each portgroup.
Example:

```
appliance-1# show portgroups
portgroups portgroup 1
state vendor-name      "F5 NETWORKS INC."
state vendor-oui        009065
state vendor-partnum    "OPT-0031      "
state vendor-revision   A0
state vendor-serialnum  "ABCD          "
state transmitter-technology "850 nm
VCSEL"
state media              100GBASE-SR4
state optic-state        QUALIFIED
portgroups portgroup 2
state vendor-name      "F5 NETWORKS INC."
state vendor-oui        009065
state vendor-partnum    "OPT-0031      "
state vendor-revision   A0
state vendor-serialnum  "ABCD          "
state transmitter-technology "850 nm
VCSEL"
state media              100GBASE-SR4
state optic-state        QUALIFIED
portgroups portgroup 3
state vendor-name      "F5 NETWORKS INC."
state vendor-oui        009065
state vendor-partnum    "OPT-0016      "
state vendor-revision   A1
state vendor-serialnum  "ABCD          "
state transmitter-technology "850 nm"
state media              10GBASE-SR
state optic-state        QUALIFIED
portgroups portgroup 4
state vendor-name      "F5 NETWORKS INC."
state vendor-oui        009065
state vendor-partnum    "OPT-0053      "
state vendor-revision   A1
state vendor-serialnum  "ABCD          "
state transmitter-technology ""
state media              25GBASE-SR
state optic-state        QUALIFIED
portgroups portgroup 5
state vendor-name      "F5 NETWORKS INC."
state vendor-oui        009065
```

system diagnostics tcpdump interface 0/0.0	tcpdump on any interface on host level. Also see: https://techdocs.f5.com/en-us/f5os-a-1-3-0/f5-rseries-systems-supportability/overview-tcpdump.html
virtctl console <tenant_name>-<tenant_instance_ID>	Will connect to the console of a tenant. See here: K33373310: Accessing an F5 rSeries tenant console

Revision #10

Created 14 November 2023 09:17:38 by Peter Baumann

Updated 8 March 2024 13:12:32 by Peter Baumann